



INSTRUCTIONS:

- Slide XLR cover and strain relief over cable first (not shown)
- Trim the Brown, Red and Green wires down to 10 mm
- Remove the existing heat shrink and fold the three wires back on themselves
- Slide 5 mm heat shrink sleeving cut to 23 mm over the three wires and shrink sleeving to secure
- Solder Black wire to Pin 1 of XLR
- Solder Orange wire to Pin 2 of XLR
- Solder Yellow wire to Pin 3 of XLR
- Slide strain relief back towards connector
- Slide XLR cover back and tighten up

PARTS LIST:

- CIF-485FTDI - USB-RS485 Cable
- CNX-M3CB1 - Male Cable Mount XLR
- WHS-BLO05 - 5 mm Heat Shrink Sleeving - Black

QUANTITY:

- 1 Off
- 1 Off
- From Reel

UNLESS OTHERWISE SPECIFIED:

ALL DIMENSIONS IN MM
 ALL COMPONENTS TO BE UL/CSA APPROVED
 ALL COMPONENTS TO BE RoHS COMPLIANT
 ANY SUBSTITUTE PARTS TO BE APPROVED IN WRITING BY XTA

© XTA ELECTRONICS LTD. THE DRAWING SHALL NOT BE COPIED, MODIFIED NOR ITS CONTENTS COMMUNICATED OR REPRODUCED IN ANY FORM AND FOR ANY PURPOSE WITHOUT THE PRIOR SPECIFIC AUTHORITY IN WRITING OF XTA ELECTRONICS LTD.

DRAWN:	Simon Moss	TITLE:	USB RS485 to Male XLR Cable
CHECKED:	Gareth Green	DRAWING NUMBER:	DASP1/12
DATE:	17-06-15	ISSUE:	1



XTA Electronics, The Design House, Vale Business Park, Worcester Road, Stourport-on-Severn, Worcestershire, England, DY13 9BZ
 Tel:- 01299 879977